



INSTRUCTION GUIDE : BST SERIES WHEELS

NEEDED:

Stan's NoTubes ZTR wheel set, 2 tires, Stan's NoTubes Tire Sealant, core remover tool, injector or 2 oz. bottle, floor pump or compressor, soapy water, safety goggles.


WARNING:

Always wear safety goggles, Sealant can stain clothes or furniture.

IMPORTANT NOTE:


Never inflate any tire without a tube above 40psi unless it is specifically labeled for tubeless use. Maximum pressure listed on your rims may differ from maximum pressure listed on your tires. Do not inflate above the lower of the two numbers.

1




Mount tire: Making sure to position the tire bead in the center channel of the rim, mount one tire bead beginning opposite the valve and finishing at the valve. Once the first bead is mounted begin mounting the second bead opposite the valve and finish at the valve.

2




With a brush or sponge apply a generous amount of soapy water to both beads of the tire to help it slip onto the bead of the rim when inflating.

3



Rotate the valve to 12 o'clock and install a pump. Inflate tire to 35psi to seat tire.


4



Add sealant: Once successful with inflation remove the valve core to add Stan's sealant. Add 2-4 oz. of sealant.


5

RECOMMENDED TIRE PRESSURE




Inflate to riding pressure; the chart above is a recommended starting point. Always review the maximum pressure information listed on both the rim and the tire and consider the lower of the two numbers your maximum pressure. Do not inflate above the lower of the two numbers.

6



Bounce: hold the wheel vertically and gently bounce or "dribble" it to disperse the sealant throughout the inside of the tire. Let it drop from an inch or two, then rotate a few degrees and repeat. Do this for several revolutions of the wheel.

7










Lay tire on side and apply a thin sheen of soapy water around the sidewall and the bead area. Look for suds occurring anywhere on the tire or bead area. Suds bubbling out from the tire indicate porous areas. Shake the sealant to those areas to seal them and apply soap and water again. Check for suds forming on both sides of the tire. Repeat until no suds remain. Install the cassette and rotors according to the component manufacturer's recommendations.

STAN'S NOTUBES BST SERIES ALUMINUM RIM SETUP GUIDE




RIMS	WEIGHT 26/27.5/29	ERD	SPOKE TENSIONS (KGF)	TAPE WIDTH Stan's Yellow Tape	VALVE
Crest MK3	326/341/364g	542/567/605	95	25mm	35mm Presta
Arch MK3	406/425/453g	542/567/605	125	27mm	35mm Presta
Flow MK3	459/480/527g	542/567/605	125	30mm	35mm Presta
Sentry MK3	498/521/556g	540/565/603	125	33mm	35mm Presta
Baron MK3	523/547/583g	539/564/602	125	36mm	35mm Presta
Iron Cross	385g	600	125	21mm	35mm Presta
Hugo	690/720/780g	552/577/614	105	27mm	32mm Schrader



* All rims are designed for disc brake use only

IMPORTANT: Stan's NoTubes strongly recommends all wheels be assembled by a professional wheelbuilder, according to the specific instructions we offer here.

- Stan's rims are drilled at an offset and at specific spoke angles to maximize strength and minimize weight. Proper drive-side and non-drive side orientation and lacing are required.
- 3-cross lacing is strongly recommended for 28 and 32-hole builds. If building a 24-hole rim, 2-cross lacing is recommended.
- Please note recommended tensions for each rim.
- Sapim Secure Lock locking nipples and Stan's SRD Spoke Powder are highly recommended.
- If assembling with Stan's hubs, spoke lengths can be found at: <https://www.notubes.com/tech-docs>
- Warranty policies for aluminum rims can be found at: <https://www.notubes.com/warranty-info>
- Tape installation and additional how-to videos are available at: <https://www.notubes.com/help>



Caution: Stan's rims are optimized for tubeless use and designed to set up tubeless with Stan's Yellow Tape, Universal Valves, and Tire Sealant. Tubes may also be used on all Stan's rims; as with all tube installations, care must be taken to prevent tubes from being caught underneath the bead of the tire, causing the tire to dismount when inflated.

Rim Tape: Stan's NoTubes Yellow Rim Tape is designed for use with all Stan's rims. Use of other tapes is not recommended. BST rims require one layer of Yellow Tape. See above chart for tape width.

Tubeless Setup: Important: Never inflate any tire without a tube above 40psi unless it is specifically labeled for tubeless use. Maximum pressure listed on your rims may differ from maximum pressure listed on your tires. Do not inflate above the lower of the two numbers.